TRADE QUALITY SINCE 1995

IP65 DUST & WATER RESISTANT INDUSTRIAL OUTDOOR 400MM WALL FAN

MODEL FA-26243 Instruction User Manual & Warranty



ACT

PRANT

CAUTION: Read the Assembly & Safety Instructions before operating and retain for future reference

DYNABAEEZE

Thank you & Congratulations on the purchase of your Dynabreeze IP65 Dust & Water Resistant Industrial Outdoor Wall Fan

To find out more information on this product, please visit **www.dynabreeze.com.au** or contact:

Tradeware

Address	45 Birralee Rd, Regency Park SA 5010		
Phone	AU 1300 658 494	NZ 0800 689 960	
Email	info@tradeware.com.au		
Website	www.tradeware.com.au		

SPECIFICATIONS



2 400MM IP65 OUTDOOR WALL FAN

Model	FA-26243
Voltage	110-240
Frequency	50/60Hz
Motor Power DC	40W
Max Speed	1250rpm
Fan Speeds	12
Wind Modes	3: Normal, Natural, Sleep
Timer	1-9hrs
Diameter	40cm
Product Weight	5.6kg

OPERATION CONDITIONS & SAFETY PRECAUTIONS

WARNING: When using electrical appliances, basic safety precautions should be followed to reduce the risk of fire, electric shock and injury to persons or property.

PLUGGING IN OUTSIDE: This fan can only be plugged into a 10 amp waterproof outdoor power point which will have a water tight cover - it is never to be plugged into a non waterproof power point when used outside.

NOTE: Always engage an electrician to install a waterproof outdoor power point.

- To avoid a hazard due to instability of the appliance, it must be placed on an even, flat surface.
- Do not operate this appliance with a damaged cord or plug after the appliance has been damaged in any manner.
- Before each use, check for any damaged parts, and have it replaced or repaired by the manufacturer or a qualified electrician.
- Connect to properly grounded power outlet only. No other appliance should be plugged into the same outlet.
- Do not run the power cord over heat insulators. Do not cover the cord. Keep cord away from traffic areas.
- Switch off and unplug the appliance before moving, cleaning or making any repairs or servicing.
- Keep safety guards/grilles in place and do not operate the machine with them removed.

WARNING: Touching of moving blades can cause serious injury.

- Do not insert fingers or anything through the grille.
- Do not wear jewellery or loose clothing that could be caught by the rotating blades.
- Never leave the appliance running unattended, turn the power off.

WARNING: Exercise caution and use reasonable supervision when appliance is used near children to ensure that they do not play with the appliance.

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge.
- Keep the area around the fan clear and suitable distance from objects that may be suctioned into the fan.

Taking care of your Wall fan


To keep your wall fan in its best condition and to protect as much as possible from exposure to moisture in the air, dust and possible rusting, we highly recommend when your fan is not in use that you wipe it dry with a cloth to ensure no water remains and place a cover over it.

DYNABACEZE


OPERATION CONDITIONS & SAFETY PRECAUTIONS


This fan is IP65 classified, which means it is dust tight and has protection against hosing jets of water from all directions. This fan is not protected from being immersed in water.

See the Ingress Protection (IP) Rating Guide below for more information.



PARTS IDENTIFICATION






- 1 Motor Head
- 2 Motor Neck
- 3 Wall Mount Plate
- 4 Remote Control



ASSEMBLY & OPERATION

Tools required



Assembling the fan

- 1. Locate the bag that contains the wall mounting hardware.
- 2. Select location to place it on the wall.

NOTE: Ensure power supply is nearby and power cord is not too tight or in a position to interfere with oscillating function.

3. Ensure the wall is suitable to support the fan:

- If mounting to a plastered wall, then the wall mount must be fitted to a stud behind the plaster wall using the screws provided.

If mounting to a brick or masonry wall, ensure plugs and screws used are suitable.
Suitable fixings must be used and must support a minimum of 8.5kg. Always check the suitability of plugs and screws for installation before use.

NOTE: The fan must be mounted vertically.

TIP: To assist in mounting the fan, a wall mounting drilling diagram is provided on the last page of this manual. Pre-drilling and fixing the mounting screws can be performed without having to hold the fan in place.

11	11	11	11	
11	11	11	11	
11	11	11	11	- 11
11	11	11	11	- 11
11	11	11	11	- 11
11	11	11	11	- 11 -
11	11	11	11	- 11
11	11	11	11	- 11
11	11	11	11	- 11
11				

STUDS


BRICK/ MASONRY

PLASTER


Т

Assembling the fan cont.

4. Using the wall mounting diagram on the last page of the manual, insert the 4 screws into the wall to a depth of approx 4cm, leaving some of the screw out from the wall. Then mount the wall fan plate over the remaining screw area and slide down until safely in place. Finally, tighten the screws so the wall fan is securely on the wall.




The fan assembly is now complete.



Operating the fan

The fan can be operated using the control panel on the unit, using the remote control or using the Smart Life app on your phone.

Operating the control panel



DYNABAEEZE

Operating the remote

Remove the protective film strip from remote to activate battery. If there is no battery, insert a new one, CR2032.


To sync remote to the unit, turn the unit on. For 2 seconds push the timer and swing button together until you hear a beep sound.

Then push the on/off button on the remote and it is now ready to use.

If it fails, the above steps may need to be repeated as sometimes the signal is not strong enough.

Modes: natural, normal, sleep

NOTE: modes can only be operated with remote control or app – not on the unit itself.



Operating with WiFi

To pair the unit with your Wi-Fi please complete the following steps:

1. Download app

Download and install the app 'Smart Life' from the App store (iOS) or Play store (Android).



2. Create account or login

Create a new account if you are a new user. Follow the prompts to set-up and complete your account.

Login with your account details if you have an existing account.

NOTE: You must agree with the Privacy Policy in order to use the app.



3. Pairing a device

Turn on bluetooth and ensure you're connected to Wi-Fi 2.4Ghz.

Open the app and tap 'add device'



Operating with WiFi

Power on the fan and push on/off button for 5 seconds - you should see the fan appear on the app after hearing a beep.

Tap add fan device and follow the instructions to connect your Wi-Fi and fan device.

After connecting successfully you'll have the option to change the name of the device.

You can now operate the device using the app. A new page should now show in the app showing controls for operating the device.



If the above instructions do not work, check the following and retry steps another time.

- 1. Fan device is in close proximity to the Wi-Fi router.
- 2. Ensure the Wi-Fi network is 2.4GHz
- 3. The Wi-Fi password is correctly entered and the same Wi-Fi network is being used on the mobile device.
- 4. The fan device is in pairing mode.
- 5. Check your Wi-Fi for stable internet connection.

If it still isn't working, visit www.ismartlife.me for more information and troubleshooting guides. (See end of manual for basic troubleshooting assistance).

Operating the fan cont.

Oscillate

Oscillation can be easily managed using the control panel, remote or app.

The oscillation range is 90°

Adjustments: Vertical Tilt Adjustment

Grip the top and bottom of the grille firmly and tilt to the desired position. If you have difficulty adjusting the vertical tilt, loosen the tilt adjustment screw slightly to give you more flexibility and then re-tighten.

DYNABAEEZE

TROUBLESHOOTING

What can I do if pairing fails with my fan device?	 Check to ensure your mobile device is connected to the 2.4GHz Wi-Fi network, refer to below for how to check the Wi-Fi frequency. Check password is correctly entered and the mobile is using the same Wi-Fi network. Check the fan device is in pairing mode, the LED indicator should be rapidly blinking to indicate pairing mode. Check the internet connection is stable and works by testing on a website.
	If problems persist, please visit www.ismartlife.me or contact the Dynabreeze Service Team on 1300 658 494 for further assistance.
Does the fan device support 5GHz wireless connections?	No, 5GHz wireless connection is not currently available for the fan device.
How do I know if my network is under 2.4GHz Wi-Fi?	 For iOS users: 1. Go to your settings and tap Wi-Fi. The suffix of your Wi-Fi network should end in either 2.4G or 5G. 2. If you still cannot determine if you are on a 2.4GHz network, you can obtain the information via your router. For more information on this process, please consult your specific router's manufacturer or user manual for more details. For Android users: 1. Go to your settings and tap Wi-Fi. 2. Tap the connected Wi-Fi network and it will show the Wi-Fi frequency.
When pairing, should my fan device or mobile be in the same room as the Wi-Fi router?	No, they do not need to be in the same room as long as they are connected to the same Wi-Fi network.
What if I forget my Smart Life app account password details?	If you forget your password, you'll have the opportunity to reset it by tapping 'forgot password' and following the prompts to reset your password.

WARRANTY

Under the Australian Consumer Law (ACL) or NZ Consumer Guarantees Act (CGA), you are entitled to a 12 month replacement or refund for product failure and compensation for any other reasonably foreseeable loss or damage.

Tradeware offers a 3 Year Warranty. The additional warranties, terms and conditions are outlined on the website **www.dynabreeze.com.au** under the Support tab.

Under Support you can also **Register your product** upon purchase and enjoy the peace of mind of knowing your product is registered should anything happen.

If the unit fails to operate efficiently, is broken or other problems arise, unplug and do not operate. Ask for advice by calling Tradeware.

To Claim, the fan should be returned to the place of purchase or via the website within the warranty period.

Such claims must include:

- · Details of the alleged defect or fault;
- · Evidence of the claim; and
- Proof of purchase documentation which clearly shows the date and place of purchase.

Please visit www.dynabreeze.com.au for more details



Tradeware 45 Birralee Road, Regency Park South Australia 5010 info@tradeware.com.au 1300 658 494

www.tradeware.com.au

Due to continual product development, please note the information and content provided may not be final and may be subject to changes.



Wall Mounting - Drilling Diagram

Tear out this page to use as a drilling guide

